






RALLY

RALLYTV


ROKU Installation Guide




Remote Control




Back




Home




Replay




Rewind



Play / Pause



Fast Forward



Options

ROKU First-time Setup

1

Remove the Roku device, HDMI cable (if included), power adapter, and remote from the box. Ensure you have two AAA batteries for the remote (usually included).

2

Connect Roku to TV

- Plug the Roku device into an available HDMI port on your TV.
- If using a streaming stick, directly plug it into the HDMI port.
- If using a box, connect the device to the TV using the included HDMI cable.

Power Up the Roku

- Plug the Roku device into a power outlet using the power adapter.
- For sticks, you may use the USB port on your TV, but using the wall adapter is recommended for consistent power.

Turn on Your TV

- Set the input/source on your TV to the corresponding HDMI port where the Roku is connected.

3

Select Your Language

- Choose the language you would like written content to be displayed in.


4

Connect Roku to Wi-Fi

- Choose your home Wi-Fi network and enter the password.
- Allow the Roku to check for updates and install them if needed.

Set Up Your Roku Account

- On-screen instructions will guide you to activate the Roku device.
- Go to your Email address on a Computer or Phone/Tablet to activate the Roku Device. Follow the steps accordingly. You do not need to add payment method for Roku features.



5

Complete Initial Setup

- Follow the on-screen steps to set up preferences, enable features like "Guest Mode" (if desired), and finalize the installation.

RallyTV App Setup

1

Access the Roku Home Screen

- Press the Home button on your Roku remote to return to the main screen.

2

Open the Roku Channel Store

- Navigate to Streaming Channels using the remote.

Search for the Rally App

- Select Search Channels and type "Rally" using the on-screen keyboard.
- When the Rally app appears, select it.

Install the Rally App

- Select Add Channel.
- Wait for the app to download and install.


Launch the Rally App

- Go to My Channels (or Home) and locate the Rally app in your installed apps list.
- Select the Rally app to open it.

3

Sign In


- Check your email to get the new login information that NIVO has provided.



4

Start Using the Rally App

- Once signed in, you can explore and use the Rally app on your Roku.



Adding an App to the Top/Favourite

1

Navigate to the Home Screen

- Press the remote to return to the home screen of your device.

2

Open the Rally App

- Scroll to find the Rally App and highlight it.

3

Access Options

- Press the [*] (options) button on your remote.

4

Move the App

- From the menu that appears, select "Move App."

5

Position the App

- Move the app to the desired top position or the favorites section.

6

Save the Changes

- Press the OK button to confirm and save the new position.